



**CUSTOM
EXHIBITS
CORPORATION**

Custom Exhibits Corp
1830 North Indianwood Ave
Broken Arrow, OK 74012
v:918-250-2121 f:918-250-1811

rollscreen 1 instructions

Install:

1. Remove bannerstand from bag. If it seems to be stuck, the bent foot on the case has caught on the cardboard insert in the padding. Remove the padding with the bannerstand and unhook the foot from the cardboard.
2. Remove shock corded three piece pole from slot in bannerstand base, assemble pole. note one end is silver, that end fits in base.
3. Twist stabilizing foot on base 90 degrees
4. Set base on floor
5. Install small hook into black end of pole
6. Put one foot on the stabilizing foot to secure hardware to the floor
7. Carefully pull up graphic with pole being careful not to rub edges of graphic on base
8. With graphic fully extended, put silver end of pole into hole on base, make sure it goes all the way in.

Dismantle:

1. Stand on the stabilizing foot to secure the hardware to the floor
2. Get a good grip on the pole and raise it out of the hole on the base. Move the bottom of the pole away from the base and slowly lower the graphic into the base. Be careful not to rub the edges of the graphic on the base.
3. Remove the pole and pull the three sections apart
5. Stand the hardware on the end with the round pin and twist the stabilizing foot to be parallel to the hardware
6. Put the three section pole into the slot on the hardware
7. Carefully return the hardware to the bag, round pin down. Be careful not to just let it drop into the bag, it will push the endpins into the hardware and make the stand inoperable.