

Congratulations on the purchase of your Graphic Banner H.

Owner's Manual

Includes:

Assembly Instructions

Storage Instructions

Care Instructions

Warranty Information

Please read all of the information carefully and contact your distributor or supplier with any issues.



Assembly Instructions

Banner H attaches horizontally to the frame. The two sets of end peg holes attach to the front of the frame, the center (top and bottom) four peg holes attach to the back of the frame. Or this can be reversed with the two sets of end peg holes attach to the back of the frame, the center (top and bottom) four peg holes attach to the front of the frame.

Storage Instructions

Store in a cool dry environment. Make sure that your graphic banner is dry before storing.

Care Instructions

Graphic banners are machine washable. Tumble dry low.

Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.